ASSEMBLY DETAILS

1

STRAIGHT BAR
CROSS PLATE
MAIN FRAME
HOOK
SUB-ASSY HOOKS

2

THE MAIN FRAME
LOCATES BETWEEN
THE CROSS PLATE
AND STRAIGHT BARS

3

REMOVE THE FINGER
TIGHT NYLOC NUTS (x4)

THE WASHERS (x4)

THE CROSS PLATE
WITH THE SPRING (x1)

4

LOCATE THE MAIN FRAME
ON THE 4 BOLTS

5

LOCATE THE CROSS PLATE
ON THE 4 BOLTS, ADD THE
WASHERS AND SCREW IN THE
NYLOC NUTS

ENSURE THE NYLOC NUTS ARE
FULLY TIGHT
USING TWO SPANNERS
ONE ON THE NUT AND
ONE ON THE BOLT AT
THE SAME TIME

ALWAYS USE AT 75° TO THE WALL,
ALWAYS FOOT THE LADDER AND
FOLLOW THE LADDER USER
INSTRUCTIONS

IT IS THE USERS
RESPONSIBILITY TO
ENSURE EVERYTHING IS
TIGHT AND UNDAMAGED
BEFORE EACH USE